

Rear Shackle Lift Kit

These shackles are designed to give most vehicles equipped with leaf springs added wheel well clearance. No special tools are required for their installation. Use all of the precautions you employ when changing rear tires. Block front wheels, engage emergency brake, etc. See your vehicle owner's manual for instructions for your particular vehicle.

Jack up the entire rear end and use jack stands or heavy duty blocks under the frame of the car when you have it elevated. Do not perform under-car work when only using a tire jack.

1. Remove the rear tires.
2. Remove the vehicle's present shackle bolts and bars.
3. Compare the size of the vehicles shackle bolts with the special bolts in this kit. If the diameters are different, or if this kit's bolts do not fit the leaf spring's eye or shackles, do not use this shackle kit. If there is any wear noted on the vehicle's springs or suspension parts, repair or replace them.
4. Install the two sets of shackle kits. Make sure the single bolt hole end of the shackles are on top, and the three holes of the shackles are mounted in the down position. When mounting the leaf springs to the shackle kit, use the set of holes that will give you the desired wheel well clearance you seek.
5. Make sure that the shackle bars are perfectly straight from top to bottom and aligned exactly together with each other.
6. Tighten the bolts to OEM specifications. See vehicle service manual or specification sheet for this information.

Recheck the shackles after driving 50-100 miles.

