

Heavy Duty Add-On Leaf Springs

These Helpers are designed to give most vehicles equipped with leaf springs added stability and load bearing ability. No special tools are required for their installation.

This kit is mounted as an assist to the existing leaf springs on your vehicle.

Prior to installing this kit, use all of the precautions you employ when changing rear tires. Block front wheels, engage emergency brake, etc. See your vehicle's owner's manual for instructions for your particular vehicle.

Jack up the rear end and use jack stands or heavy duty blocks under the frame of the car when you have it elevated. DO NOT perform under-car work when only using a tire jack.

1. Remove the rear tires.
2. Place a Leaf Spring Helper in position as seen in the illustration. Position it so the center holes of the springs match up with the tab of the vehicle's leaf spring assembly. Secure it in place by installing the two U-bolts on either side of the axle, over the leaf springs, and into the U-bolt assembly bracket plates. Use the enclosed lock washers and bolts.
3. Tighten and torque all nuts to 80-85 ft. lbs.
4. Make sure no part of the Leaf Spring Helper Kit makes contact with other vehicle parts.
5. Repeat the installation with the other side, and lower vehicle to ground. Check to ensure all parts are solid and in place.

Recheck the helpers after driving 50-100 miles.

